

INSTALLATION INSTRUCTIONS 90 DEGREE TURN CYLINDER

1. Loosen set screw (B) on knob using the Allen key. (included)
2. Remove knob (C) from body of cylinder
3. Push the pin (D) down with the auxiliary tool (E) (included). Turn cylinder shaft (A) until the follower (F) pointing down.
4. Holding in this position, insert the cylinder into the door until the follower is engaged into the lock. Insert the key and turn to operate the lock into locking position.
5. In this position, fix knob (C) on cylinder shaft (A) with set screw (B), set screw pointing downwards.
6. Tighten set screw (B). Install cylinder screw.

To Remove cylinder:

Loosen and remove cylinder screw, and repeat 1. – 3. above and remove the cylinder.

