






CES OMEGA FLEX RF-NET Access-Point and RF-NET Repeater Connections



This product information is an integral part of the assembly and operating instructions for the OMEGA FLEX RF-NET Access-Point and OMEGA FLEX RF-NET Repeater.

-  = Operative (flashing)
-  = Network connection established
-  = no connection
-  = Network connection established
-  = Data transfer

RF-NET Access-Point



RF-NET Repeater

